


SPARE PARTS LIST


FLAIR HTC-900 NUTRUNNER

ITEM NO. 49420



FLAIR HTC-900 NUTRUNNER

OVERVIEW




NO.	FL PART NO.	DESCRIPTION	Q'TY
1	49420-01	C type Retainer Ring	1
2	494032	Reaction Bar	1
3	49420-03	Internal Gear Assembly	1
4	-	-	-
5	49420-04	Internal Gear	1
6	49420-05	Lock Nut	1
7	49420-06	Gear Cage	1
8	49420-07	Planet Gear	3
9	49420-08	Pin	54
10	49420-09	Pin	3
11	49420-10	Ball Bearing	1
12	49420-11	Ball Bearing	1
13	49420-12	Bushing	1
14	49420-13	C type Retainer Ring	1
15	49420-14	Clutch Gear Assembly	1
16	49420-15	Clutch Assembly	1
17	49420-16	Washer	2
18	49420-17	Central Gear	1
19	49420-18	Gear Plate	1
20	49420-19	Pin	3
21	49415-CG-10	Pin	39

NO.	FL PART NO.	DESCRIPTION	Q'TY
22	49420-21	Planet Gear	3
23	49410-18	Rotatry Seat	1
24	-	-	-
25	49410-19	Lock Nut	1
26	49410-20	Steel Ball	4
27	49410-21	Spring	4
28	49410-22	Washer	1
29	49420-27	Central Gear	1
30	49410-24	Fixing Seat Assembly	1
31	49410-25	Cap Screw	4
32	49410-26	Cap Screw	4
33	49410-27	Ball Bearing	1
34	49410-28	Housing Cover	1
35	49410-29	Cap Screw	4
36	49420-36	Motor Housing Assembly	1
37	49410-31	Washer	1
38	49410-32	Bushing	2

FLAIR HTC-900 NUTRUNNER


FLAIR®
BRAND BY FOLKE-LARSEN

CLUTCH GEAR ASSEMBLY



NO.	FOLKE-LARSEN PART NO.	DESCRIPTION	Q'TY
1	49420-CG-01	C type Retainer Ring	1
2	49420-CG-02	Thrust Needle Bearing	1
3	49420-CG-03	Clutch Central Gear	1
4	49420-CG-04	Steel Ball	3
5	49420-CG-05	Steel Ball Seat	1
6	49420-CG-06	Wave Spring	1
7	49410-CG-02	Thrust Needle Bearing	1
8	49420-CG-08	Clutch Gear	1
9	49420-CG-09	Planet Gear	3
10	49420-CG-10	Pin	51
11	49420-CG-11	Pin	3


CLUTCH ASSEMBLY



NO.	FOLKE-LARSEN PART NO.	DESCRIPTION	Q'TY
1	49410-C-01	Cap Screw	1
2	49410-C-02	Washer	1
3	49410-C-03	Thrust Ball Bearing	1
4	49420-C-04	Upper Clutch Unit	1
5	49410-C-05	Steel Ball	3
6	49410-C-06	Lower Clutch Unit	1
7	49410-C-07	Spring	1
8	49410-C-08	Clutch Bolt	1
9	49420-C-09	Spring Seat	1

FLAIR HTC-900 NUTRUNNER

MOTOR HOUSING ASSEMBLY



NO.	FL PART NO.	DESCRIPTION	Q'TY
1	49410-MH-01	Self-Tapping Screw	9
2	49410-MH-02	Upper Housing	1
3	49410-MH-03	Lower Housing	1
4	49410-MH-04	Gear Ring	1
5	49410-MH-05	Washer	1
6	49410-MH-06	Gear Cage	1
7	49410-MH-07	Planet Gear	3
8	49410-MH-08	Needle Bearing	3
9	49410-MH-09	Pin	3
10	49410-MH-10	Washer	1
11	49410-MH-11	Gear Box Assembly	1
12	49410-MH-12	Cap Screw	4
13	49410-MH-09	Pin	8
14	49420-MH-14	Brushless Motor	1
15	49410-MH-15	LCM Board Assembly	1

NO.	FL PART NO.	DESCRIPTION	Q'TY
16	49410-MH-16	Cover	1
17	49410-MH-17	Self-Tapping Screw	2
18	49410-MH-18	PC Board	1
19	49410-MH-19	Trigger Assembly	1
20	49410-MH-20	Spring	1
21	49410-MH-21	Washer	1
22	49410-MH-22	F/R Valve	1
23	49410-MH-23	Spring	1
24	49410-MH-24	Cover	1
25	49410-MH-25	Connector Wire	1
26	49410-MH-26	Connector Wire	1
27	49410-MH-27	PCB-Storage	1
28	49410-MH-28	Self-Tapping Screw	4
29	49420-MH-29	Central Gear	1